

# ■ JBL EON ONE Compact – Quick Use Guide

## ■ Powering On/Off

- **Power On:** Press the **POWER switch** (back panel). The front LED will light up.
- **Power Off:** Hold the **POWER switch** until the light goes off.
- **Charging:** Plug in the power cable. The battery lights will climb up as it charges. Fully charged = all lights on.

## ■ Basic Controls

- **Master Volume:** Big knob = overall loudness.
- **Channel Controls (1–4):**
  - Gain = volume for that input
  - Treble = more brightness
  - Bass = more depth
  - Reverb = echo effect
- Use the **CH SELECT** button to switch between channels when adjusting.

## ■ Bluetooth Audio

1. Turn Bluetooth on, on your phone/tablet.
2. Hold the **Bluetooth button** on the speaker until it blinks.
3. On your device, select “**EON ONE Compact**”.
4. Play music – control volume from your phone or the speaker.

■ Want more control? Download the **JBL Compact Connect App** (iOS/Android).

## ■ Battery

- **Battery life:** Up to 12 hours.
- **Replace battery:**
  1. Unscrew the battery cover (back).
  2. Swap with the same model battery.
  3. Screw the cover back on.

■ That's it! Plug in a mic, guitar, or stream via Bluetooth and you're good to go.